

OPERATION

LEDS

JAMMAN EXPRESS XT QUICK START

1

RECORD

PRESS FOOTSWITCH
ONCE



REC

2

PLAY

PRESS FOOTSWITCH
ONCE



PLAY

3

OVERDUB

PRESS FOOTSWITCH
ONCE



DUB

4

UNDO/REDO

WHILE PLAYING, PRESS
& HOLD FOOTSWITCH



DUB

5

STOP

PRESS FOOTSWITCH
TWICE



REC

DUB

PLAY

6


CLEAR

WHILE STOPPED, PRESS
& HOLD FOOTSWITCH



REC

HOOKUP DIAGRAM



NOTE: For best noise performance, use an isolated power supply.